# Technical Information
Push button latches 03192-15 and clamping pins 03192-25

**1. Application:**

clamped

press

Press the latch over the clamping pin without pressing the knob. The latch is now locked.

To release, press the button and pull the latch off.

2. Function:
Four balls hold the clamping pin and clamp the plates together.

spacer ring

plate

ball

clamping pin

Production tolerances:

spacing tolerance ± 0.1

plate

base plate

spacing tolerance ± 0.1

Repeat accuracy:

A higher repeat accuracy can be achieved with the aid of additional locating pins (not supplied).

locating pin cylindrical

locating pin rhombic

Application examples:

Securing a drawer

clamping pin

Push button latches

Moving the fixture

Push button latches

clamping pin